

EASY CARE & CLEANING

RECOMMENDED CLEANING METHODS

Below are descriptions of recommended cleaning methods that must be used in conjunction with our Cleaning Chart that follows:

Dusting: Regular light dusting maintains a like new appearance for most blinds, shades, sheers and shutters.

Vacuuming: For a deep clean with your vacuum cleaner using a brush attachment. Most products may be vacuumed using a vertical stroke. Use compressed air or a hair dryer (cool setting only) to blow off dust on selected window coverings.

Spot-cleaning: Spot-cleaning shades and blinds using a soft cloth or moistened sponge with lukewarm water. You can add a mild detergent if needed. Blot gently to avoid creasing or damaging fabric. Do not rub.

Bathtub immersion: Immerse fabric in lukewarm water with mild detergent. Wash 5 minutes by gently moving liquid around with your fingers. Rinse with clear water. Re-install damp shade into window opening. Keep shade closed to allow for complete drying.

Ultrasonic cleaning: This method is used for certain products only (see cleaning chart) and should be performed by professionals.

Injection/extraction cleaning system: This type of cleaning injects a cleaning solution into the fabric and extracts the dirty solution in the same motion. This is a very effective way to deep clean. This service is typically performed by professionals.

Steaming: Steaming can be done to remove wrinkles from fabrics. A hand-held travel size steamer that provides continuous steam is best. Do not use heavy-duty steamers.

HELPFUL HINTS FOR CARE AND CLEANING

ECOWOOD OR VINYL PRODUCTS

To reduce static cling and help repel dust, wipe the product with a dryer sheet. Do not use abrasive cleaners or chemical solvents, as they will scratch or damage the surfaces.

WOOD PRODUCTS

Clean using a dry, soft feather duster, clean cloth, dust cloth or dusting mitt. A vacuum with soft brush attachment may also be used. Protect all fine wood products from exposure to steam or high moisture areas to ensure long life.

CLOTH TAPES

Spot-clean with fabric cleaning wipes found at your grocery store is recommended for all tapes. Use a gentle blotting action to clean the spot.

FABRIC SHADES, SHADINGS OR WINDOW PANEL

Do not use magnetic cleaners, such as a dusting mitt on light-dimming fabrics. While some fabric window covering products may seem perfect for an outdoor setting, all are recommended for indoor use only.

ANTISTATIC

Dry environmental conditions in different parts of the country at various times of the year may generate static on fabric home furnishings, including window coverings. Should this occur, lightly apply a static spray for home furnishings, being sure to follow manufacturer's instructions. Allow the shade to dry.

CARE AND CLEANING CHART

	DUSTING	HAND HELD VACCUUM	COMPRESSED AIR	HAIR DRYER (COOL)	BATHTUB IMMERSION	ULTRASONIC CLEANING	INJECTION/EXTRACTION CLEANING	STEAMING	SPOT CLEANING
ECOWOOD BLINDS									
Wood Art	*	*	*	*					*
Woodvue	*	*	*	*					*
Estoria	*	*	*	*					*
Matis	*	*	*	*					*
Carsan	*	*	*	*					
WOOD BLINDS									
Classic Wood	*	*	*	*					*
Carsan Wood	*	*	*	*					*
SCREENS									
Roller Blind	*	*	*	*					*
Roman Shade	*	*	*	*					*
Panel Track	*	*	*	*					*
SHEERS									
Vienna	*	*	*	*		2	3		
Ballet	*	*	*	*	1	2	3	*	
Solara	*	*	*	*					
SHUTTERS	*	*	*	*					*
DECOWOOD	*	*	*	*					*

1. For BALLETT, Bathtub Immersion Cleaning, *sheers* and *slats* only.
2. For VIENNA and BALLETT, for Ultrasonic cleaning, *sheers* and *slats* only.
3. For VIENNA and BALLETT, Injection/Extraction Cleaning, *dry* only.

Some fabrics may not be spot cleaned. Please refer to the specifications or contact our customer service department for more information.